GENUINE SPARE PARTS

H 2046 A Model Year 2012


- Use GLOBAL GARDEN PRODUCT Genuine Spare Parts specified in the parts list for repair and/or replacement.
- The contents described in the parts list may change due to improvement.
- The drawings of the spare parts are only indicative and might not represent the part in question exactly.
- The indications "right" "left" "front" "rear" refer to the position of the operator when using the machine.
- When placing orders of parts for repair and/or replacement, make sure that the illustrated parts list is the one applying to the machine's year of manufacture, as shown on the identification plate attached to the machine.

© Copyright 2012 Global Garden Products

All content is subject to copyright by Global Garden Products and may not be reproduced in whole or in part by any means, electronic or otherwise, without prior written approval.

THIS INFORMATION IS NOT INTENDED FOR SALE OR RESALE, AND THIS NOTICE MUST REMAIN ON ALL COPIES.





Position	Part No.	Q.Ty	Description
1	118800596/0	1	Right Housing, Yellow
2	118800597/0	1	Left Housing, Yellow
3	118800598/0	1	Right Handgrip
4	118800599/0	1	Left Handgrip
5	118800600/0	1	Front Handle Housing
6	118800601/0	1	Front Handle Housing Support
7	118800602/0	1	Knob
8	118800603/0	1	Switch
9	118800604/0	1	Front Handle
13	118800605/0	1	Guard
14	118800606/0	1	Support
17	118800608/0	2	Spring
18	118800609/0	1	Spring
19	118800610/0	2	Spring
20	118800611/0	1	Spring
21	118800612/0	1	Spring
29	118800613/0	1	Switch
30	118800614/0	1	Switch
31	118800615/0	1	Motor
32	118800616/0	1	Pinion
33	118800617/0	1	Sproket
42	1911-9128-01	1	Battery
43	118800618/0	1	Blades
44	1911-9129-0	1	Battery Charger