GENUINE SPARE PARTS

AGS 60 Li Model Year 2013


- Use GLOBAL GARDEN PRODUCT Genuine Spare Parts specified in the parts list for repair and/or replacement.
- The contents described in the parts list may change due to improvement.
- The drawings of the spare parts are only indicative and might not represent the part in question exactly.
- The indications "right" "left" "front" "rear" refer to the position of the operator when using the machine.
- When placing orders of parts for repair and/or replacement, make sure that the illustrated parts list is the one applying to the machine's year of manufacture, as shown on the identification plate attached to the machine.

© Copyright 2013 Global Garden Products

All content is subject to copyright by Global Garden Products and may not be reproduced in whole or in part by any means, electronic or otherwise, without prior written approval.

THIS INFORMATION IS NOT INTENDED FOR SALE OR RESALE, AND THIS NOTICE MUST REMAIN ON ALL COPIES.





Position	Part No.	Q.Ty	Description
2	1911-1640-01	1	Motor cover
4	1911-1641-01	1	Cover, LH+RH
6	1911-1268-01	5	Screw
7	1911-1642-01	1	Unlock knob (black)
8	1911-1643-01	1	Pressure spring
9	1911-1644-01	1	Switch panel (black
10	1911-1645-01	1	Fibre-optics
11	1911-1646-01	1	Eyelet
13	1911-1647-01	1	Motor incl pinion 3,6 V
14	1911-1648-01	1	Gear housing w foam
15	1911-1649-01	1	Cog wheel
16	1911-1650-01	1	Spring
17	1911-1651-01	1	Gear w eccentric
18	1911-1652-01	1	Blade
19	1911-1653-01	1	Blade protection
20	1911-1654-01	1	Blade system
21	1911-1655-01	1	Blade protection
22	1911-1656-01	1	Battery charger 350 mA, 6 V DC