



Reservdelskatalog Parts Catalogue

JB51


14-1113-17 - Season 2000

- Use GLOBAL GARDEN PRODUCT Genuine Spare Parts specified in the parts list for repair and/or replacement.
 - The contents described in the parts list may change due to improvement.
 - The drawings of the spare parts are only indicative and might not represent the part in question exactly.
 - The indications "right" - "left" - "front" - "rear" refer to the position of the operator when using the machine.
- When placing orders of parts for repair and/or replacement, make sure that the illustrated parts list is the one applying to the machine's year of manufacture, as shown on the identification plate attached to the machine.


© Copyright 2014 Global Garden Products

All rights reserved. No part of this material may be reproduced or transmitted, in any form or by any means, electronic or mechanical, including photocopying, recording or by any information storage and retrieval system, without permission in writing from GLOBAL GARDEN PRODUCTS.


www.stiga.com




Utgåva Issue 47 - 2014		Motor Spännrulle Engine Belt Tensioner			
Pos. Fig.	Antal Quantity	Art nr Part No	Benämning	Description	Anmärkning Notes
1	4	1482-0973-01	Bult	Bolt	
2	4	1482-0974-01	Mutter	Nut	
5	1	1482-0648-01	Värmeskydd	Heat Shield	
6	1	1482-0698-01	Skruv	Screw	
7	1	1482-0689-01	Bussning	Bushing	
8	1	1482-0550-01	Spännarm	Tension Roller	
9	1	9799-1031-02	Mutter	Nut	
10	1	1482-0690-01	Fjäder	Spring	
11	2	9915-0606-15	Skruv	Screw	
12	1	1482-0644-01	Remskiva-Back	Pulley-Reverse	
13	1	9600-0053-00	Kil	Key	
14	1	9915-0808-15	Skruv	Screw	
15	1	1482-0966-01	Remskiva-Fram	Pulley-Forward	
16	1	1482-0040-01	Kil	Key	
18	1	1482-0688-01	Monteringsplatta	Fitting Plate	
19	1	9997-0635-12	Skruv	Screw	
20	1	9683-0025-02	Bricka	Washer	
21	1	9799-0631-02	Mutter	Nut	
22	1	9683-0030-02	Bricka	Washer	
23	2	9987-5116-16	Skruv	Screw	
24	1	9898-0625-16	Skruv	Screw	
25	1	1482-0545-01	Fäste	Bracket	
26	1	9699-0028-02	Bricka	Washer	
27	1	9683-0025-02	Bricka	Washer	
28	1	9799-0631-02	Mutter	Nut	
29	1	9699-0028-02	Bricka	Washer	
30	1	9683-0030-02	Bricka	Washer	
31	1	9997-0816-16	Skruv	Screw	
32	1	1482-0559-01	Fjäder	Spring	
33	1	1482-0699-01	Bricka	Washer	
34	1	9997-1030-16	Skruv	Screw	
35	1	1482-0979-01	Spännrulle	Idle pulley	
36	1	1482-0689-01	Bussning	Bushing	
38	1	9650-0016-04	Sparring Sga	Circlip	
39	1	9699-0035-02	Bricka	Washer	
40	1	9799-1031-02	Mutter	Nut	
41	1	1482-0695-01	Spännarm Kpl	Idle Arm Assy	




Utgåva Issue 47 - 2014		Styre Handlebar			
Pos. Fig.	Antal Quantity	Art nr Part No	Benämning	Description	Anmärkning Notes
101	1	1482-0971-01	Bult	Bolt	
102	1	1482-0978-01	Gasreglage	Throttle Control	
103	1	9747-0631-02	Mutter Lasmutter	Nut	
105	1	1482-0659-01	Däck, Överdel-Svart	Handle, Upper-Black	
106	1	1482-0576-01	Plastvingmutter	Nut	
107	1	1482-0576-01	Plastvingmutter	Nut	
108	1	1482-0969-01	Skruv	Screw	
109	1	1482-0969-01	Skruv	Screw	
110	1	1482-0660-01	Styrrör-Svart	Handlebar-Black	
111	1	1482-0660-01	Styrrör-Svart	Handlebar-Black	
112	1	9751-0821-02	Mutter	Nut	
113	1	9683-0030-02	Bricka	Washer	
114	1	9997-0812-02	Skruv	Screw	




Utgåva Issue 47 - 2014		Koppling Clutch			
Pos. Fig.	Antal Quantity	Art nr Part No	Benämning	Description	Anmärkning Notes
200	1	1482-0565-01	Kopplingswire,Back	Clutch Cable	
201	1	1482-0563-01	Kopplingswire,Fram	Clutch Cable	
202	1	1482-0595-01	Kabelkloss	Cable Holder	
203	1	1482-0566-01	Skruv	Screw	
204	1	1482-0594-01	Spännplatta	Plate,Cable Holder	
205	2	1482-0571-01	Skruv	Screw	
207	1	9650-0010-04	Segersäkringsäkring	Circlip	
208	1	9650-0010-04	Segersäkringsäkring	Circlip	
209	1	9997-0625-16	Skruv	Screw	
210	1	1482-0572-01	Skruv	Screw	
211	1	1482-0679-01	Kopplingshandtag	Clutch Handle	
212	1	1482-0572-01	Skruv	Screw	
213	1	1482-0636-01	Spärr Hö	Catch R.H.	
214	1	1482-0637-01	Spärr Vä	Catch L.H.	
215	1	9997-0640-12	Skruv	Screw	
216	2	1482-0575-01	Handtag	Handle Grip	
217	1	1482-0675-01	Fäste	Bracket	
218	1	9747-0631-02	Mutter Lasmutter	Nut	
219	1	9747-0631-02	Mutter Lasmutter	Nut	
220	1	1482-0592-01	Fram/Back-Väljare	Forward/Reverse Selecter	
222	2	1482-0974-01	Mutter	Nut	
223	1	1482-0974-01	Mutter	Nut	
224	1	9997-0625-16	Skruv	Screw	
225	1	9699-0025-02	Bricka	Washer	
226	1	1482-0503-01	Bussning	Bushing	
227	1	9747-0631-02	Mutter Lasmutter	Nut	
228	1	1482-0972-01	Skruv	Screw	
229	1	1482-0626-01	Vinkel	Angle	
230	1	1482-0965-01	Skydd-Bakre	Sheat-Rear	
231	2	1482-0972-01	Skruv	Screw	
232	3	1482-0579-01	Remskydd	Belt Guard	




Utgåva Issue 47 - 2014		Remskiva Belt Pulley			
Pos. Fig.	Antal Quantity	Art nr Part No	Benämning	Description	Anmärkning Notes
300	1	1482-0887-01	Sprint (10X60)	Pin (10X60)	10 x 60
301	1	9799-0631-02	Mutter	Nut	
302	1	1482-0666-01	Bromssporre	Depth Skid	
303	1	9997-0635-12	Skruv	Screw	
304	1	9598-0002-02	Spännstift Fjaderpinne	Elastic Pin Spring Pin	
305	1	1482-0704-01	Remhjul	Side Wheel	
306	3	1482-0697-01	Mutter	Nut	
307	1	1482-0980-01	Remhjul	Ground Wheel	
308	1	1482-0702-01	Centrumkon	Cone	
309	1	1482-0700-01	Bricka	Washer	
310	3	1482-0696-01	Bult	Bolt	
311	1	1482-0970-01	Kil	Key	
312	6	1482-0975-01	Bult	Bolt	
313	1	1482-0977-01	Drivrem	Belt	
314	1	9585-0042-00	Kilrem	V-Belt	
315	2	1482-0974-01	Mutter	Nut	
316	1	1482-0963-01	Sidostycke-Hö	Side Member-Right	
317	2	1482-0961-01	Bussning	Bushing	
318	1	1482-0964-01	Sidostycke-Vä	Side Member-Left	
319	2	1482-0973-01	Bult	Bolt	
320	1	1482-0683-01	Remskydd	Belt Guard	
321	2	1482-0580-01	Gummistropp	Rubber Loop	
323	1	9699-0025-02	Bricka	Washer	
324	1	9739-0631-22	Mutter	Nut	
325	1	1482-0674-01	Mutter	Nut	
326	3	1482-0884-01	Skruv	Screw	
327	1	1482-0638-01	Plastskärm Hö	Outer Sheet R.H.	
328	3	9739-0631-22	Mutter	Nut	
329	1	1482-0794-01	Skärm	Sheet	
330	2	1482-0972-01	Skruv	Screw	
333	2	1482-0974-01	Mutter	Nut	
334	1	1482-0672-01	Torx Nyckel	Torx Spanner	
335	3	1482-0884-01	Skruv	Screw	
336	1	1482-0639-01	Plastskärm Vä	Outer Sheey L.H.	
337	3	9739-0631-22	Mutter	Nut	




Utgåva Issue 47 - 2014		Kedjehus Chain Case			
Pos. Fig.	Antal Quantity	Art nr Part No	Benämning	Description	Anmärkning Notes
400	1	1482-0962-01	Kedjehus Kpl	Chain Case Assy	
401	1	1482-0554-01	Bussning	Bushing	
402	1	1482-0248-01	OljepafyllningsPlugg	Oilplug	
403	4	1482-0974-01	Mutter	Nut	
404	4	1482-0677-01	Bussning	Mounting Bush	
405	24	9799-0531-02	Mutter	Nut	
406	1	1482-0668-01	Kedjehushalva, Hö	Chain Case, R.H.	
407	1	9549-0017-00	Kullager	Ball Bearing	
408	1	1482-0631-01	Ingaende Axel	Shaft W.Sprocket	
409	1	1482-0607-01	Stift	Pin	
410	1	1482-0606-01	Stift	Pin	
411	1	1482-0632-01	Bussning	Bushing	
412	1	9549-0017-00	Kullager	Ball Bearing	
413	1	1482-0633-01	Packning	Gasket	
414	1	1482-0669-01	Kedjehushalva, Vä	Chain Case, L.H.	
415	24	9997-0510-16	Skruv	Screw	
416	1	1482-0630-01	Kedjesträckare	Chain Tensioner	
417	1	1482-0514-01	Kedja	Chain	
418	1	1482-0629-01	Fjäder	Spring	
419	1	1482-0214-01	Tättningsring	Seal	
420	1	1482-0485-01	Nallager	Needle Bearing	
421	1	1482-0513-01	Drivaxel	Drive Shaft	
422	1	1482-0485-01	Nallager	Needle Bearing	
423	1	1482-0214-01	Tättningsring	Seal	
424	4	1482-0973-01	Bult	Bolt	
425	1	1482-0536-01	Växelhusholja (0.5 L)	Gear Case Oil (0.5 L)	Multifak EP00




Utgåva Issue 47 - 2014		Stödhjul Support Wheel			
Pos. Fig.	Antal Quantity	Art nr Part No	Benämning	Description	Anmärkning Notes
500	1	1482-0618-01	Las F.Hjulbygel	Wheel Fork Lock	
501	1	1482-0619-01	Fjäder	Spring	
502	1	9699-0035-02	Bricka	Washer	
503	1	9599-0071-02	Saxsprint 3.2X28	Split Pin	
504	1	1482-0691-01	Hjulbygel	Wheel Fork	
505	2	9799-1031-02	Mutter	Nut	
506	2	9683-0040-02	Bricka	Washer	
507	2	1482-0526-01	Stödhjul	Support Wheel	
508	2	1482-0521-01	Hjulbussning	Bushing	
509	2	9699-0035-02	Bricka	Washer	
510	2	9997-1060-12	Skruv	Screw	




Utgåva Issue 47 - 2014		Rotorer Rotors			
Pos. Fig.	Antal Quantity	Art nr Part No	Benämning	Description	Anmärkning Notes
601	4	1482-0887-01	Sprint (10X60)	Pin (10X60)	10 x 60
601	4	1482-0041-00	Sprint	Cotter bolt	
601	4	1482-0887-01	Sprint (10X60)	Pin (10X60)	
601	4	1482-0041-00	Sprint	Cotter bolt	
602	4	9598-0002-02	Spännstift Fjaderpinne	Elastic Pin Spring Pin	
603	8	1482-0534-01	Rotorblad Vä	Rotor Blade-L.H.	
605	32	9794-5231-02	Mutter	Nut	
606	32	9987-5222-16	Skruv	Screw	
607	8	1482-0533-01	Rotorblad Hö	Rotor Blade-R.H.	
608	1	1482-0531-01	Rotor Hö Yttre	Outer Rotor Assy-R.H.	
609	1	1482-0613-01	Innerrotor Kpl Hö	Inner Rotor Assy R.H.	
609	1	1482-0613-01	Innerrotor Kpl Hö	Inner Rotor Assy R.H.	
610	1	1482-0614-01	Innerrotor Kpl Vä	Inner Rotor Assy L.H.	
610	1	1482-0614-01	Innerrotor Kpl Vä	Inner Rotor Assy L.H.	
611	1	1482-0530-01	Rotor Vä Yttre	Outer Rotor Assy-L.H.	




Utgåva Issue 47 - 2014		Cylinder Vevhus Cylinder Crankcase			
Pos. Fig.	Antal Quantity	Art nr Part No	Benämning	Description	Anmärkning Notes
1	1	395990	Cylinder kpl	Cylinder Assy	
2	1	399268	Bussning	Bushing	
3	1	299819	Oil seal	Oil seal	
5	1	214040	Topplöck	Cylinder Head	
7	1	272157	Packning	Gasket	
8	1	495774	Vevhusventilation	Breather	
9	1	27549	Packning	Gasket	
10	2	94621	Skruv	Screw	
11	1	66578	Gummihylsa	Grommet	
12	1	270080	Packning	Gasket	
13	6	94221	Skruv	Screw	
14	2	94679	Skruv	Screw	
15	1	93448	Oil drain plug	Oil drain plug	
16	1	492088	Crankshaft	Crankshaft	
18	1	493914	Crankcase cover	Crankcase cover	
19	1	293709	Bussning	Bushing	
20	1	391484	Oil seal	Oil seal	FÖR HJÄLPAXEL
20	1	294606	Oil seal	Oil seal	
21	1	66768	Oljepåfyllningsplugg	Oil fill plug	
22	6	94682	Skruv	Screw	
25	1	298904	Kolv	Piston	
26	1	298982	Ring set	Ring set	
27	2	26026	Lasring	Lock ring	
28	1	298909	Kolvsprint	Piston Pin	
29	1	299430	Connecting Rod	Connecting Rod	
30	1	221890	Doppare	Dipper	
32	2	94745	Skruv	Screw	
33	1	211119	Exhaust valve	Exhaust valve	
34	1	261044	Insugningsventil	Intake valve	
35	1	260552	Valve spring	Valve spring	
36	1	26478	Valve spring-exhaust	Valve spring-exhaust	
40	2	93312	Retainer	Retainer	
45	2	260642	Valve tappet	Valve tappet	
46	1	212777	Kamaxel	Camshaft	
81	1	222263	Lasbleck	Lock	
219	1	494845	Governor gear	Governor gear	
220	1	221551	Bricka	Washer	
227	1	490374	Governor lever	Governor lever	
230	1	222450	Bricka	Washer	
300	1	393615	Ljuddämpare	Muffler	
306	1	224820	Shield	Shield	
308	1	224738	Cover	Cover	
337	1	1111-9028-02	Tändstift (J19Lm)	Spark Plug (J19Lm)	Champion J19LM
337	1	9400-0225-00	Tändstift (J19Lm)	Spark Plug (J19Lm)	Champion J19LM
346	2	93705	Skruv	Screw	
346	1	94680	Skruv	Screw	
358	1	495603	Packningssats	Gasket set	Märkta/marked S
383	1	1111-9029-01	Tändstiftsnyckel (19 Mm-21 Mm)	Spark Plug Wrench (19 Mm-21 Mm)	




Utgåva Issue 47 - 2014		Cylinder Vevhus Cylinder Crankcase			
Pos. Fig.	Antal Quantity	Art nr Part No	Benämning	Description	Anmärkning Notes
527	1	223786	Clamp	Clamp	
528	1	231550	Rör	Tube	
529	1	67838	Hylsa	Grommet	
552	1	231079	Bussning	Bushing	
562	1	92613	Skruv	Screw	
592	1	231082	Mutter	Nut	
613	2	93935	Skruv	Screw	
614	1	93306	Lasnål	Cotter Pin Cotter pin	
616	1	495243	Governor crank	Governor crank	
635	1	66538	Tändstiftsskydd	Spark plug elbow	
741	1	261696	Gear	Gear	
869	1	211787	Valve seat-intake	Valve seat-intake	
870	1	211436	Valve seat-exhaust	Valve seat-exhaust	
871	1	63709	Ventilstyrning-insug	Guide-intake valve	
871	1	262001	Valve guide-exhaust	Valve guide-exhaust	
896	1	211787	Valve seat-intake	Valve seat-intake	




121 CARBURETOR KIT





Utgåva Issue 47 - 2014		Förgasare Bränsletank Carburettor Fuel Tank			
Pos. Fig.	Antal Quantity	Art nr Part No	Benämning	Description	Anmärkning Notes
52	2	272585	Packning	Gasket	
90	1	496507	Förgasare	Carburetor	
95	1	93499	Skruv	Screw	
96	1	223793	Gasspjäll	Throttle Valve	
97	1	490048	Spjällsaxeln	Throttle Shaft	
108	1	491177	Choke valve	Choke valve	
118	1	231533	Nalventil	Needle valve	
121	1	495606	Carburettor kit	Carburettor kit	Märkta/marked F
124	2	94616	Skruv	Screw	
127	1	223789	Welch plug	Welch plug	
127	1	220352	Welch plug	Welch plug	
149	1	26336	Fjäder	Spring	
152	1	260575	Fjäder	Spring	
153	1	490589	Skruv	Screw	
154	1	93527	Skruv	Screw	
180	1	94620	Skruv	Screw	Ej ill/not ill.
180	1	495114	Fäste	Control Bracket	Ej ill/not ill.
180	1	94620	Skruv	Screw	
180	1	495114	Fäste	Control Bracket	
180	1	495370	Fuel tank	Fuel tank	
181	1	494559	Fuel tank cap	Fuel tank cap	
190	1	94677	Skruv	Screw	
190	3	94712	Skruv	Screw	
191	1	272489	Packning	Gasket	
201	1	262280	Governor link	Governor link	
202	1	262270	Gasreglagelänk	Throttle Rod	
203	1	280720	Bell crank	Bell crank	
204	1	222962	Bussning	Bushing	
205	1	231520	Tension Spring	Tension Spring	
208	1	262279	Reglagestang	Speed Control Rod	
209	1	262282	Fjäder	Spring	
216	1	262275	Choke link	Choke link	
217	1	262281	Fjäder	Spring	
222	1	490649	Fäste	Control Bracket	
223	1	223455	Reglagearm	Lever	
224	1	93491	Rivet	Rivet	
256	1	223813	Bell crank	Bell crank	
265	1	221535	Klämma	Clamp	
266	1	492342	Gasreglage	Throttle Control	
267	1	93496	Skruv	Screw	
392	1	262328	Fjäder	Spring	
394	1	272538	Membran	Diaphragm	
414	1	211198	Bricka	Washer	
414	1	220982	Bricka	Washer	
432	1	221377	Spring cap	Spring cap	
433	1	93265	Stift	Pin	
434	1	213963	Cover	Cover	
435	4	93141	Skruv	Screw	
526	1	94659	Skruv	Screw	



121 CARBURETOR KIT



Utgåva Issue 47 - 2014		Förgasare Bränsletank Carburettor Fuel Tank			
Pos. Fig.	Antal Quantity	Art nr Part No	Benämning	Description	Anmärkning Notes
587	1	213474	Clamp	Clamp	
611	1	297219	Fuel pipe	Fuel pipe	
621	1	396847	Stop switch	Stop switch	
629	1	261137	Fjäder	Spring	
634	1	271853	Bricka	Washer	
679	1	270382	Bricka	Foam washer	
680	1	221839	Bricka	Washer	
732	1	94414	Skruv	Screw	
733	1	94415	Skruv	Screw	
780	1	224085	Spring anchor	Spring anchor	
916	1	280324	Governor gear rack	Governor gear rack	
987	1	398970	Tätning	Seal	
995	1	223814	Länkfäste	Link bracket	
1012	1	490507	Länkhallare	Link retainer	



Utgåva Issue 47 - 2014		Luftfilter Start Air Cleaner Starter			
Pos. Fig.	Antal Quantity	Art nr Part No	Benämning	Description	Anmärkning Notes
23	1	399673	Flywheel	Flywheel	
24	1	222698	Kil	Key	
37	1	222443	Guard	Guard	
55	1	494846	Starthus	Housing	
56	1	493824	Pulley	Pulley	
57	1	262594	Fjäder	Spring	
58	1	280406	Starter rope	Starter rope	
59	1	396892	Starter Grip	Starter Grip	
60	1	393152	Inlägg	Insert	
65	4	94686	Skruv	Screw	
69	1	224322	Bricka	Washer	
69	1	280973	Bricka	Washer	
73	1	224883	Nät	Screen	
163	1	271935	Packning	Gasket	
200	1	223886	Luftledare	Air Guide	
304	1	495759	Blower housing	Blower housing	
305	4	94786	Skruv	Screw	
332	1	92284	Mutter	Nut	
333	1	397358	Armature group	Armature group	
335	2	93414	Skruv	Screw	
346	2	94680	Skruv	Screw	
356	1	398808	Kortslutningskabel	Ground wire	
363	1	19069	Avdragare	Puller	
373	4	92987	Mutter	Nut	
455	1	224250	Starter cup	Starter cup	
456	1	224321	Retainer	Retainer	
459	1	492833	Ratchet pawl	Ratchet pawl	
461	1	262626	Stift	Pin	
515	1	262625	Fjäder	Spring	
535	1	491435	Filterelement	Element	
536	1	494279	Air cleaner kit	Air cleaner kit	
608	1	495766	Rewind starter	Rewind starter	
851	1	493880	Terminal	Terminal	
966	1	492797	Luftfilterbas	Air Cleaner Base	
967	1	491588	Luftfilter	Air Filter	
968	1	495872	Cover	Cover	
969	1	490073	Skruv	Screw	
971	2	94018	Skruv	Screw	
1016	1	224278	Cover	Cover	

code	pos.	q.ty	page							
94616	124	2	p. 21	262281	217	1	p. 21	496507	90	1 p. 21
94620	180	1	p. 21	262282	209	1	p. 21			
94620	180	1	p. 21	262328	392	1	p. 21			
94621	10	2	p. 17	262594	57	1	p. 25			
94659	526	1	p. 21	262625	515	1	p. 25			
94677	190	1	p. 21	262626	461	1	p. 25			
94679	14	2	p. 17	270080	12	1	p. 17			
94680	346	1	p. 17	270382	679	1	p. 23			
94680	346	2	p. 25	271853	634	1	p. 23			
94682	22	6	p. 17	271935	163	1	p. 25			
94686	65	4	p. 25	272157	7	1	p. 17			
94712	190	3	p. 21	272489	191	1	p. 21			
94745	32	2	p. 17	272538	394	1	p. 21			
94786	305	4	p. 25	272585	52	2	p. 21			
211119	33	1	p. 17	280324	916	1	p. 23			
211198	414	1	p. 21	280406	58	1	p. 25			
211436	870	1	p. 19	280720	203	1	p. 21			
211787	869	1	p. 19	280973	69	1	p. 25			
211787	896	1	p. 19	293709	19	1	p. 17			
212777	46	1	p. 17	294606	20	1	p. 17			
213474	587	1	p. 23	297219	611	1	p. 23			
213963	434	1	p. 21	298904	25	1	p. 17			
214040	5	1	p. 17	298909	28	1	p. 17			
220352	127	1	p. 21	298982	26	1	p. 17			
220982	414	1	p. 21	299430	29	1	p. 17			
221377	432	1	p. 21	299819	3	1	p. 17			
221535	265	1	p. 21	391484	20	1	p. 17			
221551	220	1	p. 17	393152	60	1	p. 25			
221839	680	1	p. 23	393615	300	1	p. 17			
221890	30	1	p. 17	395990	1	1	p. 17			
222263	81	1	p. 17	396847	621	1	p. 23			
222443	37	1	p. 25	396892	59	1	p. 25			
222450	230	1	p. 17	397358	333	1	p. 25			
222698	24	1	p. 25	398808	356	1	p. 25			
222962	204	1	p. 21	398970	987	1	p. 23			
223455	223	1	p. 21	399268	2	1	p. 17			
223786	527	1	p. 19	399673	23	1	p. 25			
223789	127	1	p. 21	490048	97	1	p. 21			
223793	96	1	p. 21	490073	969	1	p. 25			
223813	256	1	p. 21	490374	227	1	p. 17			
223814	995	1	p. 23	490507	1012	1	p. 23			
223886	200	1	p. 25	490589	153	1	p. 21			
224085	780	1	p. 23	490649	222	1	p. 21			
224250	455	1	p. 25	491177	108	1	p. 21			
224278	1016	1	p. 25	491435	535	1	p. 25			
224321	456	1	p. 25	491588	967	1	p. 25			
224322	69	1	p. 25	492088	16	1	p. 17			
224738	308	1	p. 17	492342	266	1	p. 21			
224820	306	1	p. 17	492797	966	1	p. 25			
224883	73	1	p. 25	492833	459	1	p. 25			
231079	552	1	p. 19	493824	56	1	p. 25			
231082	592	1	p. 19	493880	851	1	p. 25			
231520	205	1	p. 21	493914	18	1	p. 17			
231533	118	1	p. 21	494279	536	1	p. 25			
231550	528	1	p. 19	494559	181	1	p. 21			
260552	35	1	p. 17	494845	219	1	p. 17			
260575	152	1	p. 21	494846	55	1	p. 25			
260642	45	2	p. 17	495114	180	1	p. 21			
261044	34	1	p. 17	495114	180	1	p. 21			
261137	629	1	p. 23	495243	616	1	p. 19			
261696	741	1	p. 19	495370	180	1	p. 21			
262001	871	1	p. 19	495603	358	1	p. 17			
262270	202	1	p. 21	495606	121	1	p. 21			
262275	216	1	p. 21	495759	304	1	p. 25			
262279	208	1	p. 21	495766	608	1	p. 25			
262280	201	1	p. 21	495774	8	1	p. 17			
				495872	968	1	p. 25			