



www.stiga.com

Illustrated Parts List

for model:

SP 46

- Use GLOBAL GARDEN PRODUCT genuine spare parts specified in the parts list for repair and/or replacement.
- Then contents described in the parts list may change due to improvement.
- The drawings of the spare part are only indicative and might not represent the part in question exactly.
- The indications "right" - "left" - "front" - "rear" refer to the position of the operator when using the machine.
- When placing orders of parts for repair and/or replacement, make sure that the illustrated parts list is the one applying to the machine's year of manufacture, as shown on the identification plate attached to the machine.


© Copyright 201 Global Garden Products

All content is subject to copyright by Global Garden Products and may not be reproduced in whole or in part by any means, electronic or otherwise, without prior written approval.


THIS INFORMATION IS NOT INTENDED FOR SALE OR RESALE, AND THIS NOTICE MUST REMAIN ON ALL COPIES.

www.ggp-group.com






SP 46				Engine parts
POS	CODE	Q.TY	DESCRIPTION	NOTES
2	118800893/0	1	Crankcase	
4	118800864/0	1	Ball bearing	
5	118800867/0	1	Oil seal	
6	118800896/0	1	Crankshaft	
7	118800897/0	1	Cylinder + piston,	
8	118800894/0	1	Piston	
9	118800884/0	2	Piston ring	
10	118800651/0	2	Washer, Piston Pin	
11	118800674/0	1	Piston pin	
12	118800888/0	1	Cylinder foot gasket	
13	118800648/0	1	Needle sleeve	
14	118800889/0	1	Gasket	
15	118800865/0	1	Ball bearing	
16	118800868/0	1	Oil seal	
17	118800869/0	1	Circlip	
18	123051000/0	1	Spark plug	
19	118800915/0	1	Deco-valve	
20	118800901/0	1	Ignition coil Aoxin	
21	118800670/0	1	Spark plug cap	
22	118800879/0	1	Short circuit cable	
23	118800902/0	1	Fan wheel	
24	118800875/0	1	Tension spring	
25	118800637/0	1	Nut	
26	118800903/0	1	Exhaust	
27	118800634/0	2	Screw	
28	118800854/0	1	Screw	
29	118800883/0	1	Air guide	
30	118800886/0	1	Muffler gasket	
31	118800662/0	2	Spring ring	
32	118800899/0	1	Manifold	
33	118800887/0	1	Manifold gasket	
34	118800900/0	1	Carburetor	
35	118800905/0	1	Air filter	
36	118800904/0	1	Filter lid	
37	118800701/0	1	Primer	
38	118800922/0	1	Hose guide	
39	118800872/0	1	Hose	
40	118800636/0	2	Screw	
41	118800924/0	1	Oil hose	
42	118800946/0	1	Oil strainer	
43	118800945/0	1	Oil pump	
44	118800629/0	5	Screw	
45	118800923/0	1	Seal	
46	118800937/0	1	Pin	
47	118800870/0	1	O-ring	
48	118800863/0	1	Bolt	
49	118800860/0	1	Washer	
50	118800933/0	1	Activator	
51	118800861/0	1	Washer	
52	118800917/0	1	Centrifugal clutch	
53	118800866/0	1	Needle sleeve	
54	118800916/0	1	Clutch drum .325"	
55	118800921/0	1	Protection cap	
56	118800943/0	1	Brake band	
57	118800660/0	1	Spring	
58	118800706/0	1	Adjuster	
59	118800938/0	1	Brake band cover	
60	118800881/0	1	Repair-kit - carburetor	
61	123878024/0	2	Screw	
62	2312280	1	Washer	
63	2432040	3	Nut	
64	2330020	6	Tension washer	
65	2312120	3	Washer	
66	3657050	1	Contact spring	
67	2135030	8	Screw	
68	2135050	1	Screw	



SP 46				Housing
POS	CODE	Q.TY	DESCRIPTION	NOTES
1	118800939/0	1	Main housing ,Yellow	
2	118800646/0	1	Pin	
3	118800911/0	1	Check valve	
4	118800937/0	1	Pin	
5	118800870/0	1	O-ring	
6	118800863/0	1	Bolt	
9	118800697/0	1	Oil tank cap	
10	118800654/0	1	O-ring	
11	118800669/0	1	Short circuit switch	
12	118800879/0	1	Short circuit cable	
13	118800665/0	3	Spring	
14	118800928/0	4	Sleeve	
15	118800855/0	1	Screw	
16	118800858/0	1	Nut	
17	118800936/0	1	Choke lever	
18	118800935/0	1	Pin	
19	118800942/0	1	Cylinder Cover Yellow	
20	118800914/0	3	Cover clips	
21	118800733/0	1	Pressure plate	
22	118800874/0	1	Spring	
23	118800857/0	2	Nut	
24	118800663/0	5	Washer	
25	118800668/0	2	Torsion spring	
26	118800672/0	2	Buffer	
27	118800906/0	1	Starter compl.,Yellow	
28	118800907/0	1	Spring cassette	
29	118800892/0	1	Rope pulley	
30	118800871/0	1	Starter rope	
31	118800890/0	1	Starter pawl	
32	118800891/0	1	Template	
33	118800876/0	1	Pin	
34	118800685/0	1	Starter handle	
35	118800859/0	1	Washer	
36	118800940/0	1	Handle housing compl., ,Yellow	
37	118800909/0	1	Fuel pick-up, compl.	
38	118800908/0	1	Fuel pick-up	
39	2312280	2	Washer	
40	118800930/0	1	Handle bar	
41	118800910/0	1	Ventilation socket	
42	118800700/0	1	Fuel Tank-Cap Ass.Y	
43	118800656/0	1	Gasket	
44	118800922/0	3	Hose guide	
45	118800873/0	1	Hose	
46	118800932/0	1	Gas lever	
47	118800878/0	1	Throttle control spring	
48	118800934/0	1	Pin	
49	118800929/0	1	Stop lever	
50	118800877/0	1	Spring	
51	118800926/0	1	Bearing safety lever	
52	118800927/0	1	Safety lever	
53	118800882/0	1	Throttle linkage 2	
54	118800925/0	1	Handle cup	
55	118800631/0	2	Screw	
56	118800880/0	1	Safety catch	
57	118800633/0	1	Screw	
58	118800912/0	1	Throttle linkage 1	
59	118800632/0	1	Screw	
60	118800947/0	1	Hand protection	
61	118800647/0	1	Sleeve	
62	118800709/0	1	Screw	
63	118800862/0	1	Rivet	
64	118800856/0	1	Screw	
65	118800941/0	1	Chain guard ,Yellow	
66	118800638/0	2	Nut	
67	118800920/0	1	Guide plate	
68	118800853/0	1	Screw	
69	118800635/0	2	Screw	
71	118800707/0	1	F. H. Screw	



SP 46				Housing
POS	CODE	Q.TY	DESCRIPTION	NOTES
72	118800655/0	1	O-ring	
73	118800919/0	1	Chain tension screw	
74	118800643/0	1	Washer	
75	118800944/0	1	Tension carriage	
76	118800717/0	1	Gear cover	
77	118800918/0	1	Support	
78	118800629/0	1	Screw	
79	118800931/0	2	Guide shoe	
80	118800624/0	1	Guide bar 15" .325"	
80	118800625/0	1	Guide bar 18" .325"	
81	4113724	1	Chain 15" .325"	
81	4113722	1	Chain 18" .325"	
82	118801123/0	1	Bucking spike	
83	2123100	3	Screw	
84	2330020	1	Tension washer	
85	2312120	1	Tension spring	
86	123878055/0	5	Screw	
87	2135120	4	Screw	
88	2123140	2	Screw	
89	112150000/0	1	Nut	