



www.stiga.com

Illustrated Parts List

for model:

SPR 270

- Use GLOBAL GARDEN PRODUCT genuine spare parts specified in the parts list for repair and/or replacement.
- Then contents described in the parts list may change due to improvement.
- The drawings of the spare part are only indicative and might not represent the part in question exactly.
- The indications "right" - "left" - "front" - "rear" refer to the position of the operator when using the machine.
- When placing orders of parts for repair and/or replacement, make sure that the illustrated parts list is the one applying to the machine's year of manufacture, as shown on the identification plate attached to the machine.


© Copyright 2014 Global Garden Products

All content is subject to copyright by Global Garden Products and may not be reproduced in whole or in part by any means, electronic or otherwise, without prior written approval.


THIS INFORMATION IS NOT INTENDED FOR SALE OR RESALE, AND THIS NOTICE MUST REMAIN ON ALL COPIES.

www.ggp-group.com







POSITION	PART No.	Q.Ty	DESCRIPTION	NOTES
1	6995173	1	Nut	
2	6995207	1	Flywheel Assy	
3	6995224	2	Screw	
4	6995208	2	Flywheel Starter Hook	
5	6995250	2	Flywheel Spring	
6	6995225	2	Washer	
7	6995247	1	Seal Ring	
8	6995170	2	Ball Bearing	
9	6995018	1	Flywheed Key	
10	6995202	1	Crankshaft	
11	6995169	2	Washer	
12	6995237	1	Needle Bearing	
13	6995200	1	Piston	
14	6995172	1	Piston Pin	
15	6995171	2	Circlip	
16	6995201	1	Piston Ring	
17	6995245	1	Cylinder Assy	
18	6995186	1	Stabilizer	
19	6995252	4	Screw	
20	6995248	1	Seal Ring	
21	6995229	4	Screw	
22	6995185	1	Muffler Gasket	
23	6995246	1	Muffler	
24	6995251	1	Plate	
25	6995182	2	Screw	
26	6995210	1	Earth Cable	
27	6995227	1	Stop Wire	
28	6995234	2	Screw	
29	6995209	1	Electronic Coil	
30	6995022	1	Spark Plug Spring	
31	6995066	1	Spark Plug Cover	
32	6995238	2	Bushing	
33	3210024	1	Spark Plug	
34	6995183	1	Intake Manifold Assy	
35	6995167	2	Screw	
36	6995212	1	Gasket	
37	6995244	1	Carburettor	
38	6995214	1	Grommet	
39	6995213	1	Choke Lever Rod	
40	6995243	1	Air Filter Support	
41	6995211	1	Plate	
42	6995168	2	Screw	
43	6995217	1	Air Filter	
44	6995216	1	Air Cleaner Cover	
51	123878008/0	2	Screw	
52	6995175	1	Front Cover	
53	6995239	1	Crankase Ass.Y	
54	6995187	2	Screw	
55	6995221	1	Breather Valve Assy	
56	6995232	1	Grommet	
57	6995193	2	Cap Ass'Y	
58	6995228	1	Air Purge	
59	6995188	1	Grommet Ass.Y	
60	6995189	1	Grommet	
61	6995174	1	Fuel Pickup Assy	
62	6995190	1	Tube	
63	123878008/0	2	Screw	



POSITION	PART No.	Q.Ty	DESCRIPTION	NOTES
64	6995249	1	Upper Cover	
65	6995194	1	Guard	
66	6995180	1	Chain Guard	
67	6995179	1	Screw	
71	6995204	1	Gasket	
72	6995223	1	Washer	
73	6995191	1	Filter Intank Assy With Pipe	
74	383594507/0	1	Oil Pump Assy	
75	323878075/0	1	Female Screw	
76	6995205	1	Tube	
77	6995008	2	Screw	
78	6995206	1	Cover Pump	
79	123878008/0	2	Screw	
80	6995230	1	Needle Bearing	
81	6995176	1	Drum Ass'Y, Clutch 3/8"	
82	6995203	1	Sprocket Washer	
83	6995177	1	Clutch Ass.Y	
84	6995241	1	Plate	
85	6995220	1	Valve	
86	6995192	1	Gasket	
87	323275005/0	1	Shock Absorber	
88	123878007/0	1	Screw	
89	323790006/0	1	Cap	
90	6995219	1	Clamp	
91	123878009/0	1	Screw	
92	6995231	1	Fair Led	
93	6995184	1	Tube	
94	6995235	1	Tube Connection	
95	6995181	1	Screw	



POSITION	PART No.	Q.Ty	DESCRIPTION	NOTES
1	383058007/0	1	Starter Assy Yellow	
2	123234000/0	1	Starter Cord	
3	3750067	1	Starter Handle	
4	123430557/0	1	Starter Spring	
5	323604001/0	1	Starter Pulley	
6	123657002/0	1	Washer	
7	123878010/0	1	Screw	
8	323107501/0	1	Air Conveyor	
9	123878008/0	1	Screw	
10	323275004/0	1	Grommet	
11	6995240	1	Handle Assy	
12	6995114	1	Spring	
13	6995134	1	Throttle Lever	
14	6995016	1	Pin	
15	6995196	1	Cap	
16	323275005/0	1	Shock Absorber	
17	123878007/0	1	Screw	
18	323790006/0	1	Cap	
19	6995226	1	Switch	
20	6995198	1	Tube	
21	6995199	2	Tube Connection	
22	6995197	1	Tube	
23	6995218	1	Rear Cover	
24	6995215	1	Throttle Rod	
25	6995135	1	Safety Lever	
26	6995195	1	Handle, Upper Part	
27	123878008/0	1	Screw	
28	123878008/0	4	Screw	
31	323790006/0	1	Cap	
32	123878007/0	1	Screw	
33	323275005/0	1	Shock Absorber	
34	323105000/0	1	Handle	
35	123878010/0	2	Screw	
36	123200001/0	1	Plate	
37	123878010/0	1	Screw	
41	123878009/0	1	Screw	
42	323311003/0	1	Bar Plate	
43	123796004/0	1	Nut	
44	123878005/0	1	Screw	
45	123510093/0	1	Pin	
46	323448001/0	1	Brake Band	
47	123665001/0	1	Needle	
48	123430561/0	1	Spring	
49	323315061/0	1	Lever	
50	123430560/0	1	Spring	
51	123120000/0	1	Nut	
52	123657003/0	1	Washer	
53	123044206/0	1	Bushing	
54	323455005/0	1	Hand Guard	
55	123430559/0	1	Spring	
56	383315050/0	1	Chain Brake Lever	
57	123665000/0	1	Needle	
58	123044207/0	1	Bushing	
59	123430558/0	1	Spring	
60	323080000/0	1	Balance Weigth	
61	123878006/0	1	Screw	
62	123878009/0	3	Screw	



POSITION	PART No.	Q.Ty	DESCRIPTION	NOTES
63	323109515/0	1	Brake Cover	
64	323059008/0	1	Clutch Housing Yellow	
65	3641380	1	Bushing	
66	2670120	1	Nut	
71	123900114/0	1	Guide Bar 10" 3/8"	
72	118801741/0	1	Chain 10" 3/8"	
73	323085000/0	1	Chain Cover	